1

BOUNCYBOING!TH

MankypantsTH

18 MONTHS +


Pump this baby up and get to hoppin' in no time!




Remove the pin before beginning to inflate.



Insert the pump and start pumping until desired fullness (don't over inflate).



Push pin back inside once Hankypants is plump. Ready, set, hop away!





Bounce on over to mybtoys.com to see more of the raucous worlds of B. Bursting with questions or comments? Call us (toll free).

1-866-665-5524

© 2018 Maison Battat Inc. B. and Bouncy Boing! and Hankypants and Just B. Just You. B. You are trademarks of Maison Battat Inc.

Manufactured for Maison Battat Inc. 8440 Darnley Road, Montreal, P.Q. H4T IM4 Designed by Maison Battat Inc. Consumer Information Line: I-866-665-5524

ATTENTION: For optimal bounce, have an adult watch you hop, and be sure to steer clear of stairs and roads. Hop on smooth surfaces only, put away your not-so-bouncy toys first, and do not over pressure Hankypants when inflating, she's very ticklish.

WARNING! Keep this toy away from fire and heat sources, as it can cause permanent damages. This toy will not bounce happily ever after if deformed by heat.

Avoid contact with furniture or painted surfaces over a long period of time to prevent discoloration

100% RECYCLED
WOOD-FREE PAPER
PRINTED WITH
SOY-BASED INKS

